

REMOTE CONTROL


PREDPLATENIE / PRIPOJENIE / AKTIVÁCIA A POUŽÍVANIE

Táto používateľská príručka vysvetlí, ako aktivovať diaľkové ovládanie Remote Control pre vaše vozidlo.

V prvom rade na používanie diaľkového ovládania Remote Control potrebujete účet MyPEUGEOT a zaregistrovať svoje vozidlo. Ak ste si ešte nenainštalovali mobilnú aplikáciu do svojho telefónu, môžete to jednoducho urobiť stiahnutím aplikácie z Google Play Store alebo App Store.



Otvorte aplikáciu MyPEUGEOT, navštívte sekciu so službami a výberom položky „Objaviť“ aktivujte diaľkové ovládanie Remote Control. Kliknite na „ZAČAŤ AKTIVÁCIU“ a aktivujte svoju novú službu.



Pokračujte na stránku Aktivácia služby, v ktorej sa dočítate, čo je to Remote Control a aké sú výhody, ktoré vďaka tejto službe získate. Prejdite nadol a kliknutím na tlačidlo „ZÍSKAŤ“ pokračujte v aktivácii služby.

Pre aktiváciu diaľkového ovládania Remote Control je dôležité prečítať si a prijať všeobecné podmienky a po uložení vašich preferencií môžete spustiť proces aktivácie prostredníctvom mobilnej aplikácie, stačí kliknúť na „POKRAČOVAŤ DO MyPEUGEOT“.

Tieto 3 kroky, ktoré musíte v tejto chvíli dodržať, vám zaberú len pár minút a na konci si môžete začať užívať diaľkové ovládanie Remote Control. Na začiatku potvrdte, že ste si už prečítali a prijali podmienky a potom spustíte aktiváciu.

The screenshot shows a mobile application interface for the MyPEUGEOT account certification process. At the top, there is a black navigation bar with a white back arrow and the text "MyPEUGEOT account certif...". Below this, the title "MyPEUGEOT account certification process" is displayed in bold black text. A paragraph explains that to control the vehicle remotely, the user must complete a ten-minute process in three steps. It also notes that the process can be paused and resumed later. The steps are listed vertically, each with a blue circle icon: 1. Define a trusted phone number, 2. Set a MyPEUGEOT safety code, and 3. Secured bluetooth connection (To do in the vehicle). Below the steps, there is a checkbox with a checkmark and the text "I agree to the terms and conditions of use". At the bottom, there is a large blue button labeled "START".

1. Zadajte svoje telefónne číslo a zadajte kód, ktorý ste dostali prostredníctvom SMS




2. Vytvorte si svoj osobný 4-miestny bezpečnostný kód. Ak chcete spustiť tento krok, dostanete dočasný kód prostredníctvom SMS. Najprv ho vložte, aby ste svoj telefón zaregistrovali, a potom vytvorte bezpečnostný kód. Tento kód vám umožní zabezpečiť vzdialený prístup k vášmu autu a používať funkcie diaľkového ovládania.

← MyPEUGEOT account certif...

MyPEUGEOT account certification process

To be able to control your vehicle remotely from your smartphone, you must complete this ten-minutes path in three steps.

You can stop it at any time and resume later.



START

× MyPEUGEOT safety code ← MyPEUGEOT safety code



Set a MyPEUGEOT safety code

This code, specific to your MyPEUGEOT account, enables us to authenticate you. Note it will be regularly requested to ensure that it is indeed you who are using the application.

START

← MyPEUGEOT safety code

We have send you a 9-digit code by SMS. You need to fill it to then set your safety code.

Received code

[Re-send me the code >](#)

CONTINUE

← MyPEUGEOT safety code

We have send you a 9-digit code by SMS. You need to fill it to then set your safety code.

Received code
1234 ✓

[Re-send me the code >](#)

Define a 4-digit safety code easy to remember to interact with your car from your smartphone.

Set the safety code

CONTINUE

| | | | | |
|-----|---|-----|---|---|
| + | 1 | 2 | 3 | % |
| - | 4 | 5 | 6 | ← |
| * | 7 | 8 | 9 | ✕ |
| / | | 0 | = | . |
| ABC | , | @?# | | 🔍 |

← MyPEUGEOT safety code

Received code
1234 ✓

[Re-send me the code >](#)

Define a 4-digit safety code to interact with your car from your smartphone.

Set the safety code
1234 ✓

Confirm
1234 ✓

CONTINUE

| | | | | |
|-----|---|-----|---|---|
| + | 1 | 2 | 3 | % |
| - | 4 | 5 | 6 | ← |
| * | 7 | 8 | 9 | ✕ |
| / | | 0 | = | . |
| ABC | , | @?# | | 🔍 |

× Change safety code



MyPEUGEOT safety code set

CLOSE

3. Pripojte svoj mobilný telefón k vozidlu pomocou Bluetooth. Choďte do svojho vozidla, zapnite motor, zapnite Bluetooth na svojom mobilnom telefóne a kliknutím na „PÁROVAŤ“ spustite spojenie.

← MyPEUGEOT account certif...
✕ Secured bluetooth connect...
← Secured bluetooth connect...
✕ Secured bluetooth connect...

MyPEUGEOT account certification process

To be able to control your vehicle remotely from your smartphone, you must complete this ten-minutes path in three steps.

You can stop it at any time and resume later.

Define a trusted phone number

Set a MyPEUGEOT safety code

Secured bluetooth connection (To do in the vehicle)

Secured bluetooth connection

Pick-up your car key, keep your phone with you, get on board and start the engine.

Make sure you are ready

- 📶 Ensure that your smartphone is connected to the Internet via Wi-Fi or cellular (3G/4G).
- 📶 Turn on the engine, connect your smartphone to your car with bluetooth connexion then click on « Next »
 - [Connect my smartphone to my car](#)
- 🔒 Your vehicle's privacy mode (private mode) must allow data sharing.
 - [Handle my car data privacy](#)

Secured bluetooth connection done

START

START

PAIR

FINISH

Teraz je služba Remote Control aktívna. Môžete byť požiadaní o aktualizáciu softvéru vášho vozidla, aby ste mohli naplno využívať všetky funkcie a spravovať svoj automobil na diaľku.

AKO POUŽÍVAŤ REMOTE CONTROL:

Po aktivácii diaľkového ovládania Remote Control pre vaše vozidlo môžete ovládať stav uzamknutia vášho auta, zamykať a odomykať dvere alebo zapnúť svetlo a klaksón.

Na diaľkové ovládanie auta stačí otvoriť aplikáciu MyPEUGEOT, vybrať ikonu príkazu, ktorý chcete poslať do svojho vozidla, potvrdiť akciu a počkať niekoľko sekúnd. Pamätajte, že každých 7 dní musíte potvrdiť diaľkové príkazy pomocou vášho bezpečnostného kódu.

The image shows three sequential screenshots of the MyPEUGEOT app interface for a Peugeot 308 Hybrid. Each screen displays the vehicle's status, service center information, and location tracking options.

- Screen 1:** Shows the vehicle is unlocked. Status: Feb. 25 2022 at 16:21. Fuel level: 453 mi. Range: 20 mi. Buttons for lock, unlock, and honk are visible.
- Screen 2:** Shows the vehicle is unlocked. Status: Feb. 25 2022 at 16:21. Fuel level: 453 mi. Range: 20 mi. Buttons for lock, unlock, and honk are visible.
- Screen 3:** Shows the vehicle is locked. Status: Feb. 25 2022 at 16:21. Fuel level: 453 mi. Range: 20 mi. Buttons for lock, unlock, and honk are visible.

Below the status cards, there are sections for:

- APPOINTMENT & ESTIMATE:** Unplugged
- MY SERVICE CENTRE:** Unplugged
- Charge management:** Unplugged
- Air conditioning:** No programming
- Plan your next journey:** Unplugged

At the bottom, there are three maps showing the vehicle's location. Below each map, it says "Last know vehicle's position" and "6 avenue general de Gaulle de la république 75000 Paris".

Below the maps, there are three sets of buttons for location tracking:

- Save vehicle's Position
- Get a route to my vehicle
- Share vehicle's Position